



# Truegrip PS

## Hand Applied Slurry Seal

### DESCRIPTION

Truegrip PS is a single pack ready to use, high quality slurry seal which is formulated from a combination of bitumen emulsion and specially selected graded aggregates. Truegrip PS cures to form a tough durable finish which is used for sealing highway and footpath reinstatements.

### USES

Truegrip PS is an easy to apply footpath, driveway and car park refurbishment surface dressing. It can also be used on tennis courts, cycle tracks, play areas and central reservations.

### ADVANTAGES

- Seals, protects and prolongs the life of bituminous surfaces.
- Improves skid resistance qualities.
- Greatly enhances general surface appearance.
- Designed for easy application by hand.
- PSV Value 71
- SRV Value 86

### COLOURS

Truegrip PS is available in black, red and green. A fine and coarse grade aggregate finish is available.

### TEMPERATURE

Truegrip PS should be applied in fine dry conditions. Cold, wet and humid conditions will delay the setting time. Laid at the recommended thickness Truegrip PS should be able to withstand foot traffic after approximately 2 – 4 hours.

COVERAGE		DRYING TIME (2-3mm thickness)	
Coarse Grade 25kg	8m <sup>2</sup> @ 2 - 3mm	At 15°C	6 – 8 hours
Fine Grade 25kg	10m <sup>2</sup> @ 1 - 2mm	At 20°C	3 – 6 hours
		At 25°C	2 – 4 hours

**Recommended Installation Thickness** - Coarse Grade approx. 2 – 3 mm / Fine Grade approx. 1.5 mm.  
Coverage will depend on the porosity of the substrate.

### INSTRUCTIONS FOR USE

#### SURFACE PREPARATION

Ensure that all surfaces are sound and free from dirt, oil, standing water, weeds and any other surface contamination. Remove all loose material from the surface using a brush/blower. Fill any potholes with patching macadam and fill narrow cracks. All perimeters should be masked with tape to produce neat edges. Manholes, drain gratings etc. should be masked to prevent contamination. Truegrip PS is not suitable for use on concrete substrates.

## APPLICATION

Truegrip PS is ready to use but after extensive storage the bag/bucket may require stirring/kneading before use. Apply using a soft bristled brush or squeegee to obtain initial even covering. Finish with a soft bristled brush to provide a uniform finish. Avoid excessive brushing as this may cause aggregate separation. A 2-3 man crew can reach coverage of up to 1000m<sup>2</sup> per day depending on conditions for large area applications.

## FINISHING

All masking tape should be immediately removed after application. All tools can be cleaned with water or if Truegrip PS has dried then please dispose of tools.

## STEP BY STEP INSTALLATION METHOD



STEP 1



STEP 2



STEP 3



STEP 4



STEP 5



STEP 6

## STORAGE & DISPOSAL

All tools and equipment should be cleaned with water immediately after use. Spillage should be absorbed with sand or sawdust and disposed of in accordance with statutory regulations. Material may be stored in original sealed packs for up to 12 months

## PRECAUTIONS

For further information on our precautions please see the MSDS.

## Technical Service and Quality Assurance

All information provided in this leaflet is based on results obtained from our own experience and testing which is given in good faith. The information is provided without guarantee as the user will be deemed to have satisfied themselves independently of the suitability of Conren's product for their own particular purpose. Conren Limited cannot be held responsible for any errors as a result of any incorrect information being provided.



[www.conren.com](http://www.conren.com)

Conren Limited. Unit 1, The Bridge Business Centre,  
Ash Road South, Wrexham Industrial Estate,  
Wrexham. LL13 9UG

Tel: +44 (0) 1978 661 991  
Fax: + 44 (0) 1978 664 664  
E-mail: [info@conren.com](mailto:info@conren.com)